




Acceptable Plug $\phi 0.64 \sim \phi 0.35\text{mm}$, Socket Pins




NZG8809-GG




NZG88094-GG



NZG88106-GG




NZG88106-GG-H
Non magnetic type




NZG88117-GG


(N88)




NZG8810-GG



NZG8811-GG




NZG8816-GG




NZG8820-GG

(N88)




N88F1315L74


How to use



(N88)



N88R150L185A-GG



Press in from this side

(N88)